


M -16

Sealless Combination Tool for Steel Strapping



M-16 PART LIST**SEALLESS COMBINATION TOOL FOR STEEL STRAPPING**

KEY NO.	PART DESCRIPTION	QUANTITY		
15-1	TENSION HANDLE	1		
15-2	SEALER HANDLE	1		
16-4	FRAME	1		
15-5	SIDE COVER	1		
16-6	FEED WHEEL SUPPORT HANDLE	1		
15-7	STRAP LIFTER	2		
15-8	PAWL SHAFT	2		
15-9	GUIDE ARM PIN	2		
15-10	SHOULDERED SCREW	1		
15-11	GUIDE ARM	1		
15-14	SEALER HANDLE SPACER	2		
15-15	EXCENTRIC SHAFT	1		
15-17	DIE HOLDER	1		
15-18	CAM FOLLOWER	1		
15-19	DIE HOLDER SHAFT	1		
15-21	DIE	3		
15-22	CUTTER BLADE	1		
15-23	FEED WHEEL SUPPORT SHAFT	1		
15-24	ROLL PIN 2x9.8	1		
15-25	CLUTCH PLUG (BOTTOM GRIPPER)	1		
15-26	FEED WHEEL	1		
15-28	RETAINING PAWL , SHORT	1		
15-29	PAWL SPRING	3		
15-30	HANDLE PAWL	1		
15-31	RATCHET WHEEL	1		
16-32	FEED WHEEL SHAFT	1		
15-33	SUPPORT PLATE	1		
15-35	ADJUSTMENT PLATE	1		
15-36	KNOB	2		
15-37	FEED WHEEL SUPPORT SPRING	1		
15-38	RETAINING PAWL, LONG	1		
15-41	WASHER	2		
15-42	ADJUSTMENT SCREW	1		
15-43	PIN 3x22	2		
15-44	STRAP GUIDE PAWL, 1/2"- 5/8"	1		
15-45	WASHER	1		
16-47	STRAP GUIDE, FRONT , 1/2"- 5/8"	1		
15-48	STRAP GUIDE, REAR, 1/2"- 5/8"	1		
15-50	STRAP GUIDE PAWL, 5/8" – 3/4"	1		
16-53	STRAP GUIDE, FRONT, 5/8" – 3/4"	1		
15-54	STRAP GUIDE, REAR, 5/8" – 3/4"	1		
15-56	RETENTION SCREW M4x8	1		
15-57	SCREW M4x8	2		
15-58	SCREW M4x12	5		
15-59	SCREW M5x10	2		
15-60	SCREW M6x10	1		
15-61	SCREW M6x14	3		
15-62	SCREW M4 x 10	1		
16-63	SCREW M8x14	1		
15-66	NUT M6	1		
16-67	SMALL BEARING	1		
15-69	LARGE BEARING	1		
15-72	SUPPORT ROLLER 2x15.8	59		
15-73	ROLL PIN 3x9.8	3		
15-77	ROLL PIN 5x25	1		
15-78	ROLL PIN 6x16	2		
15-80	WASHER	2		
16-85	RETAINING WIRE	1		